





Hypa Hub

6x SP6 for Hypa Hub mount




Superstar Hub

5xSP5 for Superstar Hub mount




6x B3 (Hypa Hub) +
5x B3 (Superstar) +


6x SP6 (Hypa Hub)
5x SP5 (Superstar)




Hub Screws +
Apply Blue Lock only on final assembly!
No Lock Paste at this stage!




2.1




*drive train on left side,
single drive "regular"*




*drive train on right side,
single drive "goofy"*





2.2




2.3




2.4






2.5



left drive train



right drive train




Step 3 E-Drive MTB




3.1


- 4x M8x16
- 1x M5x5
- 1x




3.2




3.3



Align drive perpendicular to square hanger base. Tighten up screws *bit by bit* in correct order! Start with M5 grub screw.



3.4




Stick on pre-assembled wheel. Check drive alignment! DRIVE and PULLEY should be **100% Parallel**. Look at drive top down and from the side!

Spin wheel to check pulley alignment!



3.5




Detach wheel and separate hub from pulley.







2.5 mm
4.0 mm

Take your time! This step is very important to get the drive 100% correctly aligned.



4.1



4.2





4.3




4.4


Belt Tensioning System




5.1




5.2



5.3




5.4



Step 6 E-Drive MTB

TRAMPA



f Tire and Tube, slightly inflated

c Inner Bearing
d Inner Half Hub
f Valve cutout

g Outer Half Hub

i Nylock Axle Nut

g Outer Bearing

h Hub Bolts M4

b Belt Tension Adjustment Screw

a Slightly loosen Tension Roller Axle.
Re-tension after Step 6.4

6.4

Carefully tension the Belt, using a 4mm Allen Key. Don't overtighten the Belt! HTD belts should only be tightened to the point, where any sag is eliminated + a tiny bit more.

6.1

- Slightly loosen tension roller axle
- Loosen belt tension adjustment screw
- Slide inner bearing onto axle shaft.
- Stick on inner half hub.
- Place the bearing spacer over axle shaft. **Only Superstar wheels require a rubber O-Ring, placed onto the axle shaft, next to the bearing spacers.**
- Present tire and tube to half hub, valve slotted into the valve cutout.
- Slide on outer half hub with bearing inserted.
- Feed hub bolts through hub and carefully wind the bolts into the Pulley spacers, using blue lock paste. Be careful when winding in the bolts! You don't want to cross thread them!
- Wind on nylock axle nut

6.2

Inflate Tyre to desired pressure. **Deflate before you detach the wheel, e.g. when changing you tires or tubes. Never wind out the M4 hub bolts when tire is inflated! Danger!**

6.3

Carefully tighten the wheel nut! You can't check if the wheel spins freely, since it is attached to the drive train. Try to push and pull the wheel sideways to check if any play is in the system. Tighten up the wheel nut in very small steps, until any play is eliminated. Don't tighten up any further!